



XS WIRELESS 2

Quick Guide | Kurzanleitung | Guide rapide | Guida rapida | Guía de inicio rápido | Guia rápido | Beknopte handleiding | Krótka instrukcja obsługi | Snabbguide | Kort vejledning | Pikaohje | Γρήγορος οδηγός | Kısa Kılavuz | Краткая инструкция | 快速指南 | 快速使用指南 | クイックガイド | 요약 설명서

| In the box | Vocal Sets | | Instrument Set | Lavalier Set | Headmic Set |
|-----------------------|------------|-----------|----------------|--------------|-------------|
| | XSW 2-835 | XSW 2-865 | XSW 2-CI1 | XSW 2-ME2 | XSW 2-ME3 |
| XS WIRELESS 2 | | | | | |
| EM-XSW 2 NT 12-5CW | • | • | • | • | • |
| SKM 835-XSW MZQ 1 | • | ○ | ○ | ○ | ○ |
| SKM 865-XSW | ○ | • | ○ | ○ | ○ |
| SK-XSW | ○ | ○ | • | • | • |
| ME 2-2 | ○ | ○ | ○ | • | ○ |
| ME 3-II | ○ | ○ | ○ | ○ | • |
| CI 1-N | ○ | ○ | • | ○ | ○ |
| 2 x AA LR6 1.5 V | • | • | • | • | • |

Battery

Low battery

| | |
|----------|--|
| ~ 10 h | |
| ~ 7 h | |
| ~ 3 h | |
| Low Batt | |

Setup

On/Off

Display


Volume

Mute

Sennheiser electronic GmbH & Co. KG

Am Labor 1, 30900 Wedemark, Germany, www.sennheiser.com
Printed in Germany, Publ. 02/17, 571344/A03

Change frequency



SET

Scan mode

606.500 MHz
ANT TUNE PRESET SCAN SYNC
B. 1 CH. 01

SKM/SK Off!

606.500 MHz
ANT TUNE PRESET SCAN SYNC
B. 1 CH. 01

Bank

615.400 MHz
ANT TUNE PRESET SCAN SYNC
B. 2 CH. 03

SET

SET

Preset mode

606.500 MHz
ANT TUNE PRESET SCAN SYNC
B. 1 CH. 01

Bank

606.500 MHz
ANT TUNE PRESET SCAN SYNC
B. 2 CH. 01

Channel

615.400 MHz
ANT TUNE PRESET SCAN SYNC
B. 2 CH. 03

SET

SET

Tune mode

Bank U only!


606.000 MHz
ANT TUNE PRESET SCAN SYNC
B. U CH. 00

+ 25 kHz
- 25 kHz


606.025 MHz
ANT TUNE PRESET SCAN SYNC
B. U CH. 00

SET


Sensitivity



- 0 dB
- 10 dB
- 20 dB
- 30 dB




ME 2-2




25 cm (10")

ME 3-II




2...3 cm (1")


Squelch




min. SQ



max. SQ



Sync



606.375 MHz
B. 2 CH. 03

606.500 MHz




1 hold

2

5 MHz
TUNE PRESET SCAN
H. 0 SYNC

2x




606.375 MHz
B. 2 CH. 03

Bank 2 Ch. 3
615.400 MHz

Multichannel


Bank 1...8; U
CH. 01...12



max. 12 CH.


| Bank | CH. | Bank | CH. | Bank | CH. | Bank | CH. | |
|------|-----|------|-----|------|-----|------|-----|---|
| 2 | 3 | 2 | 4 | 2 | 5 | 2 | 6 | ✓ |
| 1 | 1 | 1 | 2 | 1 | 3 | 1 | 8 | ✓ |
| 2 | 3 | 1 | 3 | 4 | 7 | 8 | 9 | ✗ |
| 2 | 3 | 2 | 3 | 2 | 3 | 2 | 3 | ✗ |

Min. distance




> 5 m (16'5")

SKM



Guitar pickup



> 20 cm (8")

